

CAMERA PLACEMENT

Because the camera is completely wire-free, you'll have a lot of flexibility with where you place it. The camera's flat base allows you to put it on a table, shelf, or anywhere with a flat surface.

The camera also comes with a separate magnetic stand which can be mounted to a wall with either the included 3M Command™ adhesive strips or screws. The stand will hold the camera in place at almost any angle.

Mounting with adhesive strips


The supplied double-sided adhesive strips work best on smooth surfaces. When applying the strips, press firmly for at least 30 seconds to achieve a stronger adhesive bond.

Mounting with screws

Use the supplied mounting template to correctly mark and drill screw holes. Then install screws (and wall plugs, if necessary) and hang the magnetic stand over the screw heads.

DISCOVER MORE

This quick start guide provides the information you need to get started. To learn more about using the mobile app, download the SAFE by Swann App Manual from our Support Center at: support.swann.com



NEED HELP?



tech@swann.com



support.swann.com



FCC Statement

This equipment has been tested and found to comply with the limits for Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and the receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC RF Radiation Exposure Statement Caution: To maintain compliance with the FCC's RF exposure guidelines, place the product at least 20cm from nearby persons.

WARNING: Modifications not approved by the party responsible for compliance could void user's authority to operate the equipment.

Frequency Range: 2.4GHz ISM Band; 5.0 GHz ISM Band

CE Output Power: 2412-2472MHz<16dBm; 5150-5350MHz<13dBm; 5470-5725MHz<13dBm

Simplified EU Declaration of Conformity

Swann Communications declares that this device is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU. A copy of the Declaration of Conformity can be found at: www.swann.com/uk/compliance

Correct Disposal of this product. This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environment safe recycling.




ENGLISH

Smart Security Camera

Wire-Free HD Video Camera

QUICK START GUIDE

CAMERA OVERVIEW



- 1 Night detection sensor
- 2 Microphone
- 3 Infrared LEDs for night vision
- 4 Passive infrared motion sensor
- 5 LED indicator
- 6 Reset pinhole button
- 7 Pairing button
- 8 USB charging port
- 9 Port cover
- 10 Magnetic mount holder

CHARGE THE CAMERA

Before using the camera for the first time, charge it for at least two hours with the included USB cable.

- 1 Open the port cover on the back of the camera.
- 2 Plug the smaller end of the USB cable into the USB charging port on the camera, and the larger end into a USB wall charger (DC5V 2.1A or above is recommended for faster charging).
- 3 Actual charging time depends on the USB power supply and the remaining battery level. A full charge can take up to six hours if the camera battery is nearly empty.


TIP Once you have set up your camera, you can easily check the charging progress using the SAFE by Swann app the next time you charge it.

GET THE APP


Download and install the latest version of the SAFE by Swann app from the Apple App Store® or Google Play™ Store on your iOS or Android device. Simply search for "SAFE by Swann".



FIRST TIME SETUP



Open the SAFE by Swann app. Create an account or sign in if you already have an account.



Tap **Pair Device** and follow the on-screen instructions to set up Wi-Fi and register the camera to your account.