



W²⁵ **Hanger Webcam**

SW385-WH5
www.swannsecurity.com

SW385-WH5-60010-290909

Before you Begin

FCC Verification:

NOTE: This equipment has been tested and found to comply with the limits for Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and the receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

Package Contents

- W-25 Webcam
- Software CD-ROM
- Operating Instructions



Technical Specifications

Image Sensor	1/4" Color CMOS
Max. Resolution	2560 x 1920 (5 Mega Pixels)
Video Format	24-bit RGB / YUY2
Frame Rate	30fps @ 640 x 480 15fps @ 1600 x 1200
Focus Range	5cm - ∞
White Balance	Automatic
Microphone	Yes
Audio Range	9ft / 3m
Dimensions	110mm x 75mm x 40mm 4.3" x 3.0" x 1.6"
Weight	110g / 2oz

Minimum System Requirements

Interface Type	USB 2.0
Processor	Pentium IV or above
RAM	1GB or greater
Video Card	Intel 945 or greater
Hard Drive Space	Minimum 1GB free
Operating System(s)	Microsoft® Windows® XP Microsoft® Windows® Vista Microsoft® Windows® 7 Mac® OS X® 10.x*

*Cyberlink software not compatible with Mac.

*Windows is a trademark of Microsoft Corporation in the United States and other countries.
Mac is a registered trademark in the United States and other countries.*

Connection Guide

For best results, install the software on the included CD-ROM before connecting the W-25 to your computer.

- Locate a free USB 2.0 port on your computer.
- Attach the W-25's USB plug directly to the free USB 2.0 port.
- Do not use a USB hub, nor a USB extension cable, as these can interfere with the webcam's connection to your computer, and compromise performance.
- If you're running a compatible operating system (see opposite), the W-15 will automatically be detected and drivers will be installed. A popup dialog box will alert you once drivers have been installed.
- There is no need to restart your computer if you connect/disconnect the W-15 webcam. Like most USB devices, it supports "hot-swapping".
- To physically mount the W-25 Webcam, use the base folded down as a stand, or fold the base and use it as a clamp to attach the W-25 to your LCD screen or notebook display.

Placement Tips

Where you put the W-25 is really up to you, but here are a couple of suggestions.

- The W-25 will automatically adjust exposure levels (that is, how bright everything in the image appears to be) unless manually overridden. Thus, if you're sitting in front of a bright light source (such as a window) and you are in shadow, the difference in brightness might cause you to 'under expose' and appear only as a silhouette. We suggest trying to keep everything the camera sees evenly lit.
- Any camera generally gives better results being set up higher than the subject and looking down, rather than looking up at it. This is particularly true of faces - it's not so flattering seeing up one's nose! Thus, we suggest mounting the W-25 level with yourself or slightly above.

Included Software

We've included all the software you'll need to run the W-25 on the included CD-ROM. Please note that the included software requires a Microsoft Windows operating system - see Technical Specifications opposite.

Installation

- Insert the CD-ROM.
- If the program does not run automatically, then open the CD-ROM drive in Windows Explorer, and double-click "autorun.exe".
- Select your desired language.
- Follow subsequent instructions on screen.
- Support documentation for the software is available on the CD-ROM.

Please note: The included software is created, licensed and supported by *Cyberlink*, a leading video software application group. If you require any support or further assistance, visit *Cyberlink's* web site, located at www.cyberlink.com

Help Desk & Technical Support

Swann Technical Support

All Countries E-mail: tech@swannsecurity.com

Telephone Helpdesk

USA toll free

1-800-627-2799

(Su, 2pm-10pm US PT)

(M-Th, 6am-10pm US PT)

(F 6am-2pm US PT)

USA Exchange & Repairs

1-800-627-2799 (Option 1)

(M-F, 9am-5pm US PT)

AUSTRALIA toll free

1300 138 324

(M 9am-5pm AUS ET)

(Tu-F 1am-5pm AUS ET)

(Sa 1am-9am AUS ET)

NEW ZEALAND toll free

0800 479 266

INTERNATIONAL

+61 3 8412 4610

See <http://www.worldtimeserver.com> for information on time zones and the current time in Melbourne, Australia compared to your local time.

Warranty Information

Swann Communications USA Inc.

12636 Clark Street

Santa Fe Springs CA 90670

USA

Swann Communications PTY. LTD.

Building 4, 650 Church Street,

Richmond, Victoria 3121

Australia

Swann Communications warrants this product against defects in workmanship and material for a period of one (1) year from it's original purchase date. You must present your receipt as proof of date of purchase for warranty validation. Any unit which proves defective during the stated period will be repaired without charge for parts or labour or replaced at the sole discretion of Swann. The end user is responsible for all freight charges incurred to send the product to Swann's repair centres. The end user is responsible for all shipping costs incurred when shipping from and to any country other than the country of origin.

The warranty does not cover any incidental, accidental or consequential damages arising from the use of or the inability to use this product. Any costs associated with the fitting or removal of this product by a tradesman or other person or any other costs associated with its use are the responsibility of the end user. This warranty applies to the original purchaser of the product only and is not transferable to any third party. Unauthorized end user or third party modifications to any component or evidence of misuse or abuse of the device will render all warranties void.

By law some countries do not allow limitations on certain exclusions in this warranty. Where applicable by local laws, regulations and legal rights will take precedence.



© Swann Communications 2009