





Smart Home Outdoor Camera

At a Glance

Thank you for choosing the **Smart Home Outdoor Camera**. Please take a moment to familiarize yourself with key areas of the camera.



Get Started in Four Easy Steps



Limited Warranty Terms & Conditions

Swann Communications warrants this product against defects in workmanship and material for a period of one (1) year from its original purchase date. You must present your receipt as proof of date of purchase for warranty validation. Any unit which proves defective during the stated period will be repaired without charge for parts or labour or replaced at the sole discretion of Swann. The end user is responsible for all freight charges incurred to send the product to Swann's repair centres. The end user is responsible for all shipping costs incurred when shipping from and to any country other than the country of origin.

The warranty does not cover any incidental, accidental or consequential damages arising from the use of or the inability to use this product. Any costs associated with the fitting or removal of this product by a tradesman or other person or any other costs associated with its use are the responsibility of the end user. This warranty applies to the original purchaser of the product only and is not transferable to any third party. Unauthorized end user or third party modifications to any component or evidence of misuse or abuse of the device will render all warranties void. By law some countries do not allow limitations on certain exclusions in this warranty. Where applicable by local laws, regulations and legal rights will take precedence.

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.


CE marking on this product represents the product is in compliance with all directives that are applicable to it.

Correct Disposal of this Product

This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environment safe recycling.


1 Attach Antenna

Screw the Wi-Fi antenna onto the antenna connector. For best reception, leave the antenna in a vertical position.



2 Connect Ethernet Cable


Connect the camera directly to your internet router using the included Ethernet cable.



TIP The Ethernet cable is only required for initial setup. Configure the camera to connect to your Wi-Fi network directly during registration then go wireless.

3 Power Camera

Plug the camera into a wall outlet using the included power adapter.



4 Register Camera

Creating a Smart Home Account

Before you can set up your camera, you will need to create a Swann Smart Home account. Your Swann Smart Home account is what you use to connect devices and manage your Smart Home system and services. To sign up for a free account, go to: home.swannone.com.

Setting up your camera

Sign in to the Smart Home portal at home.swannone.com. Then follow the on-screen instructions to add the camera to your Smart Home account. Once setup is complete, download the **Home Protect** app from the Apple App Store or Google Play. Simply search for "Home Protect". The **Home Protect** app lets you view live video feed from your camera remotely using a smartphone or tablet.

