




Smart Home Motion Sensor

At a Glance


Thank you for choosing the **Smart Home Motion Sensor**. The **Smart Home Motion Sensor** detects movement in a surrounding indoor area, triggering actions and alerting you on your smartphone when it's important.



Compliance Information

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

 CE marking on this product represents the product is in compliance with all directives that are applicable to it.



Correct Disposal of this product

This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environment safe recycling.

Battery Safety Information




Caution: Keep batteries away from small children. Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries promptly in accordance with local regulations.

Limited Warranty Terms & Conditions

Swann Communications warrants this product against defects in workmanship and material for a period of one (1) year from its original purchase date. You must present your receipt as proof of date of purchase for warranty validation. Any unit which proves defective during the stated period will be repaired without charge for parts or labour or replaced at the sole discretion of Swann. The end user is responsible for all freight charges incurred to send the product to Swann's repair centres. The end user is responsible for all shipping costs incurred when shipping from and to any country other than the country of origin.


The warranty does not cover any incidental, accidental or consequential damages arising from the use of or the inability to use this product. Any costs associated with the fitting or removal of this product by a tradesman or other person or any other costs associated with its use are the responsibility of the end user. This warranty applies to the original purchaser of the product only and is not transferable to any third party. Unauthorized end user or third party modifications to any component or evidence of misuse or abuse of the device will render all warranties void. By law some countries do not allow limitations on certain exclusions in this warranty. Where applicable by local laws, regulations and legal rights will take precedence.

Need Help?


	USA & Canada	1800 627 2799	Australia	1800 788 210
	UK & Europe	0808 168 9031	New Zealand	0800 479 266
	tech@swann.com			
	support.swann.com			

Activating the Motion Sensor

- 1 Open the Motion Sensor by pushing back the release catch on top and lifting off the rear panel.



- 2 Remove the battery tab to engage the battery and activate the Motion Sensor.




Pairing the Motion Sensor

- 1 From the Smart Home web portal, click or tap **My Settings > Motion Sensors > add device**. The System Setup screen is displayed and your Smart DVR/Hub automatically goes into pairing mode.

Note: You can skip this step if the System Setup screen is already displayed, for example, during the Smart DVR/Hub registration process, or when setting up other Swann Smart Home accessories at the same time.

- 2 Press the **Connect** button on the Motion Sensor. The status LED blinks once. When the Motion Sensor has paired with your Smart DVR/Hub, the status LED blinks twice.




- 3 Follow the on-screen instructions to complete the setup.

Mounting the Motion Sensor

Place the Motion Sensor around your home as required using the included Command™ Strip. Please note that the Motion Sensor should be placed indoors only.

Note: Avoid mounting the Motion Sensor near heaters, air conditioners, light bulbs, where rapid temperature changes can occur, or facing a window where sunlight can be reflected.

- 1 Before applying the Command™ Strip, clean the surface where the Motion Sensor will be mounted, and make sure it is dry.
- 2 Fit the Motion Sensor with the Command™ Strip, and then press the Motion Sensor firmly onto surface for 30 seconds.
- 3 Test the Motion Sensor by walking across the area being monitored. The Status LED blinks whenever movement is detected, and depending on the mode your system is armed in, you will also get a motion detection alert.



Ideal sensor positioning where direction of movement is across the sensor

Troubleshooting

The Motion Sensor is not pairing with my Smart DVR/Hub

Reset the Motion Sensor - press and hold the Connect button until the status LED blinks rapidly. Then, try pairing the Motion Sensor again.

The Motion Sensor no longer detects movement

The Motion Sensor is running low on battery power. You can check the Motion Sensor's battery status via the Smart Home portal: **My Settings > Motion Sensors**. If a Low Battery symbol is shown, replace the batteries in the Motion Sensor with two fresh "AAA" alkaline batteries immediately.

The Motion Sensor is offline

- An internet service outage may have occurred. Check to make sure that your broadband router is working properly and you are able to access the internet with your other electronic devices. Once your internet service is back up, the Motion Sensor will automatically rejoin the system.
- The Motion Sensor is not be within range of your Smart DVR/Hub. Try installing the Motion Sensor closer to your Smart DVR/Hub. After relocating the Motion Sensor, press the **Connect** button to rejoin the system.

The Motion Sensor generates false alerts

Pets, and flying or crawling insects, such as spiders, can cause false alerts to occur. Check for any cobwebs in front of the motion detector and clean the space around the Motion Sensor.

I want to re-locate the Motion Sensor. How do I remove the 3M Command™ Strip?

For instructions on removing 3M Command™ strips, refer to: http://www.command.com/wps/portal/3M/en_US/NACommand/Command/Resources/How-to-Use/. Extra 3M Command™ strips are available for purchase online and at many retail hardware stores.