

Helpdesk/Technical Support

Technical Support E-mail: tech@swann.com

Telephone Helpdesk

USA Toll Free 1-800-627-2799

USA Parts & Warranty 1-800-627-2799

(M-F, 9am-5pm US PT)

AUSTRALIA 1800 788 210

NEW ZEALAND Toll Free 0800 479 266

UK 0808 168 9031



M815AF191015E | © Swann 2015

Limited Warranty - Terms & Conditions

Swann Communications warrants this product against defects in workmanship and material for a period of one (1) year from its original purchase date. You must present your receipt as proof of purchase for warranty validation. Any unit which proves defective during the stated period will be repaired without charge for parts or labour or replaced at the sole discretion of Swann. The end user is responsible for all freight charges incurred to send the product to Swann's repair centres. The end user is responsible for all shipping costs incurred when shipping from and to any country other than the country of origin.

The warranty does not cover any incidental, accidental or consequential damages arising from the use of or the inability to use this product. Any costs associated with the fitting or removal of this product by a tradesman or other person or any

other costs associated with its use are the responsibility of the end user. This warranty applies to the original purchaser of the product only and is not transferable to any third party. Unauthorized end user or third party modifications to any component will render all warranties void. By law some countries do not allow limitations on certain exclusions in this warranty. Where applicable by local laws, regulations and legal rights will take precedence.

For Australia: Our goods come with guarantees which cannot be excluded under Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality.

5

FCC Verification

This equipment has been tested and found to comply with the limits for Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and the receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

These devices comply with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) These devices may not cause harmful interference.
- (2) These devices must accept any interference received, including interference that may cause undesired operation.

6



Super HD 4x Zoom Auto-Focus Security Camera

For use with Swann 7285 & 7300 Series HD NVRs

EN

INSTRUCTION MANUAL

Important Instructions


1. Before connecting the camera, you must perform a firmware upgrade on your NVR first. Please have a look at the upgrade instructions included.
2. Make sure the camera is fixed correctly and stable if fastened in place. Do not operate if wires and terminals are exposed.
3. Never place any strain of any kind on the network cable connection. It's designed to clip into place to prevent slippage, but it won't support any weight and can be easily broken by a sharp tug.
4. As your NVR provides power to the camera, the camera's power connection is not used.
5. To perform a factory reset, disconnect the camera from your NVR, hold down the reset button, reconnect the camera and continue holding the button for at least 20 seconds then release.

6. This camera can only be used in combination with Swann's NVR-7285 and NVR-7300 series HD network video recorders.
7. For instructions on how to use the zoom and auto-focus functions, and how to configure your camera, please consult the NVR's user manual available at support.swann.com.
8. Have a look at the camera location tips included with your NVR, to select the best location for your camera (the camera location tips provided here are for general purposes only).

Important note - All jurisdictions have specific laws and regulations relating to the use of cameras. Before using any camera for any purpose, it is the buyer's responsibility to be aware of all applicable laws and regulations that prohibit or limit the use of cameras.

1


Connecting your Camera



 If you have a NVR-7285, you need to change the recording resolution to 1080P - consult the NVR's user manual for more information.

2

Positioning & Mounting your Camera



The camera has three points of articulation. The most obvious are the two hex screws that secure the elbow joint located just below the centre of the stand **(2)**. Using an Allen key, loosen each screw and adjust to the position you want (up or down). Tighten each screw again to secure in place.

The second point of articulation **(1)** is the radial joint where the neck of the stand is attached directly to the camera. This enables you to rotate the camera left or right so no matter what direction the camera is facing, your images will be oriented correctly. Loosen each screw and position accordingly. Tighten each screw again to secure in place.

To rotate the camera stand left or right **(3)**, loosen the hex screw towards the bottom of the stand and position accordingly. Tighten the screw again to secure in place.

The camera can be mounted onto a flat vertical or horizontal surface and must be of sufficient strength to hold the camera. Position the camera in the location you want to mount to then mark the mounting holes on the surface to position the screws. Using the appropriate screws for the surface you are mounting to, screw the camera into place.

3

Camera Location Tips

Some things to consider when choosing a location -

1. What you want to monitor and where you'll get the best view of it.
2. How you're going to connect the camera to your monitoring system; remember that cables and connections should be kept out of the weather.
3. It is recommended to mount your camera at an elevated position to minimise harm.
4. Place your camera as close to the area of interest as practicable. The best position is from about 4m (13ft) above looking slightly down, keeping in mind the details you are looking for.
5. Although the sky looks nice when you look at the live view from your camera, it is an unlikely direction for an offender to approach, make sure your camera has minimal sky in it as the light in daylight can make the foreground of the image darker.
6. Think about the most likely way a potential offender may approach your home, use your cameras to give you the best coverage of these areas.
7. The camera's casing is resistant to water, different weather conditions and tampering. It would take an overwhelming event of this kind to damage the housing of the camera. However, the cable and connector are vulnerable and require protection.
8. Even though the camera is weather and water-resistant, prolonged exposure to adverse weather conditions such as sunlight or excessive moisture, may eventually damage the internal components of the camera and adversely affect its performance.
9. Avoid bending your cables at sharp angles.
10. Don't put your cable near live electrical wiring. AC electricity generates radio "noise" which can interfere with the signal from your camera.

4